

Keyboard Country

Scan the appropriate country code below to program the keyboard for your country. As a general rule, the following characters are supported, but need special care for countries other than the United States:

@ | \$ # { } [] = / ' \ < > ~



* United States



Belgium



Italy



Brazil



Canada (French)



Netherlands (Dutch)



Czech Republic



Denmark



Poland



Finland (Sweden)



France



Romania



Germany/Austria



Greece



SCS



Hungary



Israel (Hebrew)



Spain



Latin America



Russia



Switzerland (German)



Norway



Slovakia



Portugal



Sweden