


9322 functions setting

* means factory default setting

Buffer mode



^&D15&^


* disable



^&D16&^

enable

Inverse barcode



AB260

disable



AB262

* enable


GS function



^&053&^


ALT

+



DY000

enable GS



DY010

* disable GS

testing code



A

A[GS]



ABC123

SIZE:100 Byte 56789
123456789 123456789
123456789 123456789
123456789 123456789
123456789 123456789



v1.2 2020.06.05