

2.4G and Bluetooth scanner prefix and suffix setting		
Suffix Terminator character Setting Add character format: Decode Data + Terminator.		
 ^&300&^ Suffix-None		 ^&301&^ Suffix-Enter
	 ^&302&^ Suffix-Line	
 ^&303&^ Suffix-Tab		 ^&304&^ Suffix- Enter & Line
Add prefix and suffix Settings		
 ^&308&^ Add Prefix setting		 ^&309&^ Add Suffix Setting
	 ^&305&^ Saved and Finished Set	
 ^&051&^ enable function key		 ^&002&^ factory default

Add Prefix (number and letter) setting

Example: add "0202" as prefix in "ABCDEFGHijklmn":

- 1: scan "Add Prefix setting"
- 2: can barcode "0" "2" "0" "2"
- 3: Scan "Saved and Finished Set"

note: scan "Add Prefix setting" + "Saved and Finished Set" to cancel prefix

Add Prefix (function key) setting

Example: add "F7" and "insert" as prefix in "ABCDEFGHijklmn":

- 1: scan "Add Prefix setting"
- 2: scan barcode "F7" "insert"
- 3: Scan "Saved and Finished Set"
4. Scan "enable function key"

note: scan "Add Prefix setting" + "Saved and Finished Set" to cancel prefix

Add suffix (number and letter) setting

Example: add "0202" as suffix in "ABCDEFGHijklmn":

- 1: scan "Add suffix setting"
- 2: can barcode "0" "2" "0" "2"
- 3: Scan "Saved and Finished Set"





note: scan "Add suffix setting" + "Saved and Finished Set" to cancel suffix

Add suffix (function key) setting

Example: add “F7” and “insert” as suffix in “ABCDEFGHJKLMN”:

- 1: scan “Add suffix setting”
- 2: scan barcode “F7” “insert”
- 3: Scan “Saved and Finished Set”
4. Scan “enable function key”

note: scan “Add suffix setting” + “Saved and Finished Set” to cancel suffix

ASCII Code Table		
	 ^&400&^ SOH	
 ^&401&^ SOH(start of headline)	 ^&402&^ STX (start of text)	 ^&403&^ ETX
 ^&404&^ EOT	 ^&405&^ ENQ	 ^&406&^ ACK
 ^&407&^ BEL	 ^&408&^ BS	 ^&409&^ HT
 ^&40A&^ LF	 ^&40B&^ VT	 ^&40C&^ FF
 ^&40D&^ CR	 ^&40E&^ SO	 ^&40F&^ SI
 ^&410&^ DLE	 ^&411&^ DC1	 ^&412&^ DC2
 ^&413&^ DC3	 ^&414&^ DC4	 ^&415&^ NAK
 ^&416&^ SYN	 ^&417&^ ETB	 ^&418&^ CAN
 ^&419&^ EM	 ^&41A&^ SUB	 ^&41B&^ ESC

 ^&41C&^ FS	 ^&41D&^ GS	 ^&41E&^ RS
 ^&41F&^ US	 ^&420&^ SP	 ^&421&^ !
 ^&422&^ “	 ^&423&^ #	 ^&424&^ \$
 ^&425&^ %	 ^&426&^ &	 ^&427&^ .
 ^&428&^ (	 ^&429&^)	 ^&42A&^ *
 ^&42B&^ +	 ^&42C&^ ,	 ^&42D&^ -
 ^&42E&^ .	 ^&42F&^ /	 ^&430&^ 0
 ^&431&^ 1	 ^&432&^ 2	 ^&433&^ 3
 ^&434&^ 4	 ^&435&^ 5	 ^&436&^ 6
 ^&437&^ 7	 ^&438&^ 8	 ^&439&^ 9
 ^&43A&^ :	 ^&43B&^ ;	 ^&43C&^ <
 ^&43D&^ =	 ^&43E&^ >	 ^&43F&^ ?
 ^&440&^ @	 ^&441&^ A	 ^&442&^ B

 C	 D	 E
 F	 G	 H
 I	 J	 K
 L	 M	 N
 O	 P	 Q
 R	 S	 T
 U	 V	 W
 X	 Y	 Z
 [	 \	]
 ^	 _	 ,
 a	 b	 c
 d	 e	 f
 g	 h	 i

 ^&46A&^ j	 ^&46B&^ k	 ^&46C&^ l
 ^&46D&^ m	 ^&46E&^ n	 ^&46F&^ o
 ^&470&^ p	 ^&471&^ q	 ^&472&^ r
 ^&473&^ s	 ^&474&^ t	 ^&475&^ u
 ^&476&^ v	 ^&477&^ w	 ^&478&^ x
 ^&479&^ y	 ^&47A&^ z	 ^&47B&^ [
 ^&47C&^ 	 ^&47D&^]	 ^&47E&^ ~
 ^&47F&^ DEL	 ^&480&^ Caps Lock	 ^&481&^ Funtion key F1
 ^&482&^ Funtion key F2	 ^&483&^ Funtion key F3	 ^&484&^ Funtion key F4
 ^&485&^ Funtion key F5	 ^&486&^ Funtion key F6	 ^&487&^ Funtion key F7
 ^&488&^ Funtion key F8	 ^&489&^ Funtion key F9	 ^&48A&^ Funtion key F10
 ^&48B&^ Funtion key F11	 ^&48C&^ Funtion key F12	 ^&48D&^ PrintScreen
 ^&48E&^ Scroll Lock	 ^&48F&^ Pause	 ^&490&^ Insert

 ^&491&^ Home	 ^&492&^ Page Up	 ^&493&^ Delete
 ^&494&^ Page Down	 ^&495&^ End	 ^&496&^ Right Arrow
 ^&497&^ Left Arrow	 ^&498&^ Down Arrow	 ^&499&^ Up Arrow
 ^&49A&^ Num Lock (keypad)	 ^&49B&^ / (keypad)	 ^&49C&^ * (keypad)
 ^&49D&^ - (keypad)	 ^&49E&^ + (keypad)	 ^&49F&^ Enter (keypad)
 ^&4A0&^ 1 (keypad)	 ^&4A1&^ 2 (keypad)	 ^&4A2&^ 3 (keypad)
 ^&4A3&^ 4 (keypad)	 ^&4A4&^ 5 (keypad)	 ^&4A5&^ 6 (keypad)
 ^&4A6&^ 7 (keypad)	 ^&4A7&^ 8 (keypad)	 ^&4A8&^ 9 (keypad)
 ^&4A9&^ 0 (keypad)	 ^&4AA&^ . (keypad)	AB~CF
 ^&4D0&^ L-Ctrl Press	 ^&4D1&^ L-Shift Press	 ^&4D2&^ L-Alt Press
 ^&4D3&^ L-GUI Press	 ^&4D4&^ R-Ctrl Press	 ^&4D5&^ R-Shift Press
 ^&4D6&^ R-Alt Press	 ^&4D7&^ R-GUI Press	
 ^&4D8&^ L-Ctrl Release	 ^&4D9&^ L-Shift Release	 ^&4DA&^ L-Alt Release

 ^&4DB&^ L-GUI Release	 ^&4DC&^ R-Ctrl Release	 ^&4DD&^ R-Shift Release
 ^&4DE&^ R-Alt Release	 ^&4DF&^ R-GUI Release	E0~FF